STREAM CLUB

CLUB CL55

INSTALLATION DIAGRAM

Under Bench Option



These instructions must be followed in order to validate your warranty.

*Minimum 15cm air envelope around all side of appliance with minimum 25cm for condenser ventilation outlet – one side of under bench space must remain open

STREAM WATER APPLIANCES

(07) 3394 4000
sales@streamwater.com.au
streamwater.com.au

Always Refreshing